

# SIM800H Download Tool\_V1.04\_User Guide

## 1. USB download

### 1-1.Preparation

1. If you upgrade module FW using SIM800H EVB board, connect the USB port which is on sim800H TE board to your computer by **USB** cable. Insert the power DC.
2. Install USB Driver” MTK\_USB\_DRIVER”.

### 1-2.Download Tool Setting:

Double click (  ) to open the download tool, you can see the interface as below:




Figure 1

**Target** : module identification; please choose “SIM800H”  
**PortType**: USB download or UART download; please choose “USB”  
**Com**: Do not choose;  
**Baud rate**: Do not choose;  
**Erase Type**: please choose Erase source code and user data (default).

### 1-3. Image Folder

Confirm compiler FW path. If it is not default path, click the “Image Folder” and navigate to the correct FW path where the where the FW file (.cfg) is in. (for example: 1308B03SIM800H32.cfg)




Figure 2

### 1-4.Start download

(1) Turn on the **download** key .If you do not have this download key in your own developed board, pull the **power key low (to GND)** all the time during downloading.









